



Hardwood Decking Tiles

organic contemporary



Tile dimensions: 12" x 12" X or 12" x 24"

Tile Thickness: 1.25"

Density of Hardwood: 2200-3680 Janka

Fire rating ; Class A UBC1 (Ipe)

Zinc Oxide or Stainless Steel screws secure hardwood to frame.

Load rating: 16000 lbs dead weight

Pre Treated with non toxic timber oil

Frame or tile base is made from recycled content polypropylene with UV stabilizer

Temp Variations from +130F to -100F

Straight edge reducers and corner pieces available for finished edges.

Certified hardwoods either FSC or similar 10 year full manufacturers warranty

Applications: Multi unit high-rise balconies, backyard patios, roof decks, old weathered wood decks or anywhere you need a quick great looking temporary floor.



Wood Species

- Ipe (Pau Lope / Iron Wood)
- Backing Detail allows for drainage and water evaporation



Deck Tile Information

Environmental Benefits

All wood purchased from certified forestry.

Wood used are the "shorts", these are pieces that are traditionally burned for charcoal. Instead we make a beautiful floor out of them.

Less wood used to create an even more stunning deck than a traditional deck built with the same wood.

No demolition, keep your concrete slab or old deck where it is and cover it, no need for landfill additions.

No toxic chemicals or plastics.



Installation Guidelines

There are no adhesives, nails, screws or special tools to worry about - the precision made modular tiles simply click together for a perfect result every time. No uneven gaps, no nail heads or screw holes, just a great looking deck you'll be proud to admit that you installed all by yourself. You may need to cut the tiles to fit odd sizes and corners. We recommend a carbine tipped or diamond blade jigsaw for cutting the tiles and a rubber mallet for easy installation.

5 Easy Steps for Installation

1.) Clean and sweep the surface clean, if it is a waterproof surface you may want to re-seal the surface before installing the tiles.

2.) Start laying the tile. It is recommended to start laying the tile on one side and work your way out to the edges. If dealing with an odd shape start with the leading edge that is most straight and work your way toward the terminating edge of your home. You can use a rubber mallet to snap tiles in place by hitting the tiles gently on all corners. If the tiles do not snap in from the top easily, try snapping them in from the bottom of the adjacent tile instead of the top.

3.) If you require custom fitting then you will need to modify some tiles on your final row. First try to remove the wood and cut the backing frame to the desired size. If your design needs a rounded shape you will need to cut across the wood slats. When cutting the tiles remember to remove the screws on your line so as to avoid hitting them with your blade.

4.) Fit your custom tiles into place for the final fitting. It is not uncommon to install rectangular and square decks in a few hours.

5.) We recommend sealing the tiles with a good oil penetrating sealer such as Cabot Australian Timber Oil (we like the mahogany flame tint) or Messmers Exotic Hardwood Sealer. The more tint or color in the oil the longer they last. These oils simply wipe on and cleanup the excess oil. Do not apply in direct sunlight. Best results occur when 2-3 coats are applied during the first application. Let dry between applications.